



L10	FREQUENCY	L12
A: R00	400-450MHz	A: 18n
B: 33P	450-470MHz	B: 10n

使用番号	欠番
R1 ~ R23	
R60 ~ R66	
C1 ~ C30	C28
C81 ~ C98	C99
C155 ~ C173	

TR1, 2, 3, 4, 5, 6, 15, 16, 17
D1, 2, 3, 4, 5, 6, 7, 8
L2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13

0001 RADIO BOARD (TX. PART)
PCB# 0001-4-1B

8/28/2000

FN URTX C7