

LXA RADIO BOARD (TX PART)

PCB 9305-4-1B

F/N LXTX.C.D.

1998/11/13

1999/8/30

L/N 12345678

	L2	L3	L4	L5	L6	L7	L8	L9	L23	L24	L25	L26	IC1
LX70	BR2	BR3	BR4	2.7uH (LAL04)	BM3	BM3	BR5	BR5	JUMPER SHORT	R1uH	0.22uH (LAL03)	JUMPER SHORT	M67742
LX150	BK13	AY51	BK13	AU-20	BG-5	BG-5	AY51	AY51	BK-12	R56uH	BK-11	BK-10	M67741
LX200 BAND I	BM-3	BM-4	BM-4	AU-20	BM-3	BM-3	AY51	AY51	BK-11	R56uH	BK-10	JUMPER SHORT	M67730
LX200 BAND III													
LX230	BQ-3	BQ-2	BQ-2	AU-20	BM-3	BM-3	BG-5	BG-5	BK-10	R56uH	BQ-1	JUMPER SHORT	M68729

	C1	C3	C4	C5	C8	C8A	C9	C9A	C10	C29	C30	C85	C86	C87	C88	C90	C92	C93	C95	C96	C161	C162		R11	R65			
LX70	0.01	27P	18P	43P	47P	6P	36P	24P	0.01	16P	0.01	*	100P	*	24P	0.001	39P	51P	0.001	39P	47P	27P		10	10			
LX150	0.001	9P	6P	30P	33P	*	15P	*	0.001	10P	0.001	8P	30P	10P	10P	100P	10P	100P	*	8P	24P	22P		10	10			
LX200 BAND I	0.001	8P	6P	24P	24P	*	12P	*	0.001	7P	0.001	6P	47P	10P	*	100P	10P	100P	*	9P	18P	12P		JUMPER SHORT	4.7			
LX200 BAND III																												
LX230	0.001	7P	5P	20P	20P	*	10P	*	0.001	3P	0.001	6P	47P	10P	*	100P	7P	100P	*	7P	15P	8P		JUMPER SHORT	3.3			

